

Patch 8

The Drum and Bass Patch

SYNC To synchronize sequencer tempo with the drum machine, patch the **SYNC OUT** on the sequencer to the **SYNC** input on the drum machine. For more on **synching**, see Patch 9!

Gate Out triggers music envelopes in time with the drum machine.

Tempo control for sequencer and drum machine (when synched).



SUM: Output to DUAL FX module, a VCA 'in' (below) or to DAW or Mixer.

Knobs control individual drum sounds (level, tone, decay, tuning).

Buttons select which drum instrument you are programming.

MASTER OUT Volume control.

Drum machine step sequencer.

Root (base) tuning controls for bass sound.

CV pitch input from the step sequencer.

Envelope shaping for VCA control.

Envelope amount for VCA modulation.



Input from drum machine.

Effects to Mixer or to DAW

Community Music Schools of Toronto

YORK UNIVERSITY

RElab